



TITLE: ELO PAY 7


SHOWN WITH ELO PAY 7 SOLO
P/N: E863808












ELO PAY 7 STANDARD RIGHT-ANGLE USB-C CABLE
IMPORTANT NOTICE:
1. PLEASE INSERT THE PLUG WITH CABLE COVER & SCREW FASTEN IN PLACE
2. CABLE NEEDS TO INSERT IN THE REAR RECESS
3. WHILE REMOVING PLUG, PLEASE PULL THE TAB. DON'T GRAB THE CABLE TO FORCE THE PLUG OUT.

DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A


SHOWN WITH OPTIONAL VESA MOUNT
P/N: E220684

TITLE: ELO PAY 7 + VESA MOUNT



<VESA MOUNT: E220684>






<ELO PAY 7 + VESA MOUNT>


DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A

TITLE: ELO PAY 7 + SMALL HUB


SHOWN WITH OPTIONAL SMALL HUB
P/N: E815044








<SMALL HUB: E815044>






<SMALL HUB + METAL BRAKET>


DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A


TITLE: ELO PAY 7 + LARGE HUB


SHOWN WITH OPTIONAL LARGE HUB
P/N: E815235












<LARGE HUB: E815235>

DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A

TITLE: ELO PAY 7 + BASIC STAND

SHOWN WITH BASIC STAND
P/N E815422



<ATTACH VERSION:ELO PAY 7 + BASIC STAND>



ELO PAY 7 STANDARD USB-C CABLE
(BETWEEN THE HUB & MONITOR/AiO)


ELO PAY 7 STANDARD RIGHT ANGLE USB-C CABLE
(BETWEEN THE HUB & PAY 7)
IMPORTANT NOTICE:
1. PLEASE INSERT THE PLUG WITH CABLE COVER & SCREW FASTEN IN PLACE
2. CABLE NEEDS TO INSERT IN THE REAR LEFT RECESS
3. WHILE REMOVING PLUG, PLEASE PULL THE TAB. DON'T GRAB THE CABLE TO FORCE THE PLUG OUT.


DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A


TITLE: ELO PAY 7 + POS STAND


SHOWN WITH POS STAND+PAY7
P/N: E814473



















DIMENSIONS ARE IN MILLIMETERS

MS603418
DATE: 06.07.2024
REV: A


TITLE: PRINTER WEDGE STAND


SHOWN WITH PRINTER WEDGE STAND
P/N E815808






<OPEN TRAY STATUS>
1. REPLACE PAPER
2. ATTACH PAY 7






<PRINTER WEDGE STAND>



<SECURE SCREW>




<PRINTER WEDGE STAND + BASE PLATE>

DIMENSIONS ARE IN MILLIMETERS


MS603418
DATE: 06.07.2024
REV: A


TITLE: ELO PAY 7 + PRINTER WEDGE STAND


SHOWN WITH PRINTER WEDGE STAND + PAY 7
P/N E814661




ELO PAY 7 STANDARD RIGHT ANGLE USB-C CABLE
IMPORTANT NOTICE:
1. PLEASE INSERT THE PLUG WITH CABLE COVER & SCREW FASTEN IN PLACE
2. CABLE NEEDS TO INSERT IN THE REAR LEFT RECESS
3. WHILE REMOVING PLUG, PLEASE PULL THE TAB. DON'T GRAB THE CABLE TO FORCE THE PLUG OUT.











<PRINTER WEDGE STAND + PAY 7>



<SECURE SCREW>



<ELO PAY 7 + PRINTER WEDGE STAND-OPEN>

DIMENSIONS ARE IN MILLIMETERS

MS603418
DATE: 06.07.2024
REV: A