



Ti300U, Ti400U, Ti401U, Ti480U Thermal Imagers




To download SmartView IR software, visit www.fluke.com/smartview-ir.
要下载 SmartView IR 软件, 请访问 www.fluke.com/smartview-ir。




1 ⓘ




2a AF




2b MF



3



4



5

